





Contents:

1 Cornhole Board 4 Metal Stakes 1 Storage Bag 8 Bean Bags 8 Sticky Balls

3 Games, 4 Ways to Play



Tic-Tac-Toe

Grab the bean bags, separate them by color and take turns placing them on the board. First person to get three in a row wins!



Classic Bean Bag Toss

Lay the pop-up board down and take turns throwing the bean bags into the holes. The person with the most points wins!



Standing Bean Bag Toss


Flip the pop-up board upright and take turns throwing the bean bags into the holes. The person with the most points wins!



Sticky Ball Toss

Flip the pop-up board around and grab the sticky balls. Throw them at the board and see who can score the most points!


Fold it Up and Take it Anywhere!



Pull the panels apart and fold panel 1 down followed by panel 2.



Grab opposite sides of the now folded panels and twist in opposite directions.



Twist until 3 circles are formed and fold them down on one another.



Overlap 2 of the circles with the circle at the other edge.



Line up the edges so that the board is folded as neatly as possible. Place in the included bag.

CHOKING HAZARD-SMALL PARTS NOT FOR CHILDREN **UNDER 3 YEARS**









FOR MORE INFORMATION

Visit us online at www.usatoyz.com for product information and replacement parts. Questions or comments? Please contact us at support@usatoyz.com for fast friendly service.

WARNING: PLEASE READ BEFORE USING YOUR PRODUCT. Do not allow children to climb on the constructed structure. Teach your child to use this toy responsibly and supervise them while playing. Inspect the product before playing and discard any item that appears damaged.

Do not place the product near an open flame or other heat-emitting electrical devices (e.g. lamps, space heaters). Do not puncture bean bags or bring near sharp objects. Keep away from children under 3 years of age. The game board pops out quickly when opening it up. Keep away from face. Keep metal stakes away from children, eyes and mouth.