

Multiplayer Laser Tag Game



LAZER TAG RECHARGE

Laser Blaster Operating Instructions

Please read the following instructions carefully.



1. **Start:** Insert **Fully Charged** batteries and turn on your laser blaster by switching the **Power Switch** to the "on" position.
2. **Team Selection:** Press the **Switch Teams** button until you receive a voice prompt. Choose which team you are on from the four options. The team indicator lights up with the chosen color (Red, Green, White, or Blue).
3. **Weapon Selection:** Press the **Blaster Type** button to choose from 5 different blaster types. Single-Shot, Laser Blaster, Shotgun, Machine Blaster, or Submachine Blaster. Each weapon has a different attack and bullet count. When switching between blaster types, make sure that the cartridge is loaded with bullets by pressing the reload button.
4. **Blaster type:**
 - Single-Shot - 9 bullets, 1 life lost per hit
 - Laser Blaster - 9 bullets, 1 life lost per hit
 - Shotgun - 6 bullets, 2 lives lost per hit
 - Machine Blaster - 6 bullets, 2 lives lost per hit
 - Submachine Blaster - 6 bullets, 2 lives lost per hit
5. **Single-Shot/Rapid-Fire Button:** The default setting is single-shot. To switch to rapid-fire, press the **Single-Shot/Rapid-Fire** button. You will receive a voice prompt. Pulling the trigger will give the corresponding sound effect. Press the button again to switch back to single-shot.
6. **System Reset:** When you only have 3 lives left, the system will give you the voice prompt of "Low life volume." When all your lives are gone the system broadcasts "Game over" and you lose all combat capability. The system will remind you every 15 seconds until the power is turned off or the system is reset. To reset the system, use the power button to re-activate your weapon.
7. **Low Battery Warning:** As the **Blaster Indicator Light** begins to dim and the screen shows "00" and the LCD screen shows "00", it's time to recharge the battery.

Note: The shooting distance between blasters and vests is 98ft.



Laser Tag Vest Functionality

1. Insert (1) 3.7V Li-ion fully charged battery.
2. Add purified water to the vest through the top inlet. Do not fill above the indicated water level line.
3. Turn on the vest, use a blaster to shoot the vest so it will sync with chosen team.
4. When your last life is gone, the Team Indicator will show the team color of the attacker and the sprayer is triggered to spray water. Your Vest will cease to work until it is reset.
5. Each player has 9 lives. Every time a player is hit, life light will flash and the vest will vibrate. When all lives are gone, the light will turn off.
6. Turn the Power Switch to the ON position to reset and play again.



Maintenance

1. Remove batteries when not in use.
2. Clean regularly with a clean, damp cloth.
3. Store in a place not directly exposed to sunlight.
4. Do not immerse in water.
5. **Use only the provided rechargeable batteries. Do not use standard batteries.**
6. Drain water from vest before storing.
7. If this toy has been unused for a long time, make sure to fully charge batteries first before playing again.

Notice:

If the numerical display of the product shows "00" and you are prompted to "Please replace the battery", it means that the battery power is low. Please charge the batteries when low.

Warning:

Do not alter or tinker with the product without authorization as it may lead to product failure.


Charging instructions

1. Insert batteries into charger.
2. Insert the USB plug into the power adapter socket and switch on the charger. The charging indicator light will light up red to indicate that it is charging.
3. The light will turn off once charging is complete.
4. Unplug charger and remove batteries.

Note: Charging time is approximately 2 hours.

Important:

Observe correct battery polarity before charging exhausted batteries. Do not charge non-rechargeable batteries or different types of batteries to avoid damages.



Battery use and charge safety instructions

1. Each laser tag blaster uses (1) 3.7 Li-ion battery.
2. Install batteries according to the correct polarity as shown in the battery compartment.
3. Only use the indicated battery type to avoid damaging the product.
4. In case of visible damages, stop using the toy, charging cords, and other accessories.
5. Only use the included charger to charge the batteries. Charging light indicator lights up red when the battery is charging. The light will turn off once charging is complete.
6. When the battery life is exhausted, remove battery from the toy and charge it before storing.
7. Batteries should not be left unattended while charging.
8. Do not overcharge batteries.
9. Unplug charger when not in use.

Quick Start Guide



Problem	Problem cause	Solution
Product will not turn on.	Battery not installed correctly.	Reinstall batteries correctly or use new batteries.
	Power switch is off.	Check to make sure power switch is on.
Product fails to hit target.	Target you are shooting at is a teammate.	Shoot only at other team.
	Bullets not added after changing blaster type or you have exhausted the ammunition.	Press reload button to reload.
	Opponent is beyond shooting distance. Range of blaster is 98ft.	Shorten the distance between you and your opponent.
	There is an obstacle between shooter and target.	Avoid obstacles.
Product not working normally.	Battery is low. The battery indicator light is weak.	Charge batteries fully. (Only for rechargeable batteries)
	Using the product under bright glare.	Play in an area without a glare.
	Other infrared devices are interfering (Like TV remote control.)	Do not use around other infrared devices.



Please include your order number when you contact us at support@usatoyz.com for fast, friendly service.