



INSECT ZAPPER

Dear Customer,

Please read these user instructions carefully before connecting the appliance in order to prevent damage due to incorrect use. Read the safety instructions in particular very carefully.

Sincerely,

The Livin' Well Team

HOW THE BUG ZAPPER WORKS:

This Smart Bug Zapper utilizes the black light (ultra-violet rays) of the wave length, which is proved to be the most effective lure for light sensitive flying insects, such as mosquitoes, gnats, and other small flying insects. These insects are electrocuted by the high voltage inner grid. No chemicals, no smell, no sprays, no mess, pollution free and harmless to humans and pets. It is ideal for using in houses, office, factories, food outlets, hospitals and other places.

SAFETY PRECAUTIONS:

1. High voltage! Do not touch the inner electric grids.
2. Never put metal objects inside the grids while in operation.
3. This product is for household use only. Suitable for indoor and outdoor use.
4. Keep away from areas where flammable vapor or explosive dust is likely to exist.
5. Check the local voltage before operating.
6. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
7. This product is not a toy. Keep this appliance and its cord out of reach of children.
8. Keep this appliance away from any water or liquids. An electric shock hazard may occur if the appliance is in contact with liquids.
9. When using extension cords, keep the socket-outlet away from moisture and avoid damage to the cord.
10. The appliance can be used on a flat surface, or hung using the attached chain on areas with at least 4k bearing supports.
11. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard. Any other servicing should be performed by an authorized service representative.
12. Unplug the appliance before cleaning. Clean the plastic enclosure with dry cloth and empty the bottom collection tray every week as needed.

Have any questions? Contact us at support@shoplivinwell.com

IMPORTANT SAFETY INSTRUCTIONS

READ ALL INSTRUCTIONS BEFORE USING;

KEEP AWAY FROM WATER

1. The extension cords are available.
2. The devices for retaining an extension cord connection to the power supply cord are available.
3. The product is for household use only.
4. Use extension cord marked SJW-A, SJEW-A, or SJTW-A only.
5. Use only extension cords which have plugs and receptacles which accept the product's plug. Replace or repair damaged cords.
6. The electrical rating of the extension cord must be as great as the electrical rating of the product.
7. Don't Abuse Cord – Never carry product by cord or yank it to disconnect from receptacle. Keep cord from heat, oil, and sharp edges.
8. Disconnect the product from the power supply when not in use, before servicing, when changing bulbs, cleaning, and similar actions.
9. Do not insert foreign objects into this product.
10. Outdoor extension cords must be used with outdoor use products and are surface marked with suffix letters "W-A" and with a tag stating "Suitable for Use with Outdoor Appliances.
11. The connection to an extension cord should be kept dry and off the ground.
12. Store products indoors when not in use – out of reach of children.
13. This appliance is not intended for use by children and other persons whose physical, sensory, or mental capabilities or lack of experience and knowledge prevents them from using the appliance safely without supervision or instruction by a responsible person to ensure that they can use the appliance safely.
14. Children should be supervised by the responsible person to ensure that they do not play with the appliance.
15. Do not clean this product with a water spray or similar method.
16. The product should only be connected to a circuit that is protected by a ground-fault circuit-interrupter (GFCI).
17. CAUTION - Risk of UV exposure. Ensure product is installed such that no continuous human activity is likely to be performed within 0.99m distance of the unit while illuminated
18. WARNING: An electric shock hazard may exist if water from a garden hose is directed at the insect killer.
19. When using extension cords, keep the socket-outlet away from moisture and avoid damage to the cord.
20. The appliance is not to be used in locations where flammable vapour or explosive dust is likely to exist.
21. DANGER: High voltage.
22. WARNING Skin or eye damage may result from directly viewing the light produced by the lamp in this apparatus. Always disconnect power before servicing.
23. **User maintenance**
Any other servicing should be performed by an authorized service representative, such as: Lamps intended for service replacement only by service person, not by user.
24. Double Insulation – When servicing, use only identical replacement parts.

SAVE THESE INSTRUCTIONS