POWER PARAMETERS

Two options for powering your Cityscape Globe:

3 x AAA batteries or Power Supply Type-C Cable (5V 500mAh)

When operating by battery alone, if you have the LED on and the globe rotating, the batteries should last approximately 9 hours.

When using the Type-C USB Power you will see a red indicator light next to the port on the base of the globe.

Warning: When using the USB power supply only use a source that is 5V 1A or lower, Using a more powerful supply can cause damage or shorting out.

For fast, friendly service email support@usatoyz.com



This product should be assembled by adults. Contains small parts that could be a choking hazard. Not meant for children under 3 years of age.

The contents may vary from the illustration on package












support@usatoyz.com















SETUP

1. Put 3 x AAA batteries into the battery compartment on the bottom of the base. Use new batteries and install them according to the correct polarity. Batteries are not required for the globe to power on, you can use the power cord alone.



⊕⊗⊙

2. After the northern and southern hemispheres are connected, place the globe on the connector, with the northern hemisphere at the top.

FUNCTION DESCRIPTION



LED Timer

Make sure you have the LED turned on. Press the timer button once to enter 15 minute mode (the LED will flash 1x), press it a second time to enter 30 minute mode (the LED will flash 2x), press it a third time to enter 60 minute mode (the LED will flash 3x). Please note if you do not have the LED turned on, no LED indicator will flash to signal which timer mode you are in.



LED On/Off

Press once to turn the LED on, press a second time to turn the LED off.



Rotation On/Off

Press once and the globe will begin rotating, press a second time and the globe will stop rotating.

ACTION KEY	FEATURES	
Rotation	On/Off	0
LED	On/Off	*
LED Timer	Timing Functions	(15) (36) (60)